

2-Man Modular Blind Parts
AeroOutdoor.com
508-545-8000

2. Drip Door

1. Front Panel

14. Wire Locks
to connect the panels

3. End Frame - no door top Stabilizer

4. Top Stable Panel

5. Back Panel

No HOOK STABILIZERS ONLY

8. End Door Frame

2. pieces

6. Vertical Stabilizer

needed to attach
the door hinges.

7. Door Frame

5. Door Hinges

30. Door Slit

17. Drop Door Hinges

12. Strands - top

12. Strands - bottom

www.aerooutdoors.com

Call us at 508-545-8000 and find us at our design & build

